


ENTRY SLIDE HAMMER

Model J10003


MOTOR GUARD

- ① Slide nosepiece over draw pin and rotate thumbwheel back. While holding wheel, tap weight back gently to 'set' pin.

LOCK



PULL



- ② Operate slide hammer as you normally would, taking care not to pinch fingers.

- ③ To release pin, tap slide weight gently against nosepiece while rotating thumbwheel forward.

- ④ In case of a stuck pin, drive nosepiece forward firmly to free wheel.

RELEASE

